

Product Support Bulletin 2003-008

NORDCO Inc. 182 W. Oklahoma Avenue, Milwaukee, WI 53207


Contact: Gary D. Van Deluyster, Service Manager – Phone: 800-445-9258 – Fax: 414-769-2140

Maintenance of Way ~ Work Equipment Bulletin


DATE:	October 28	3, 2003		
SUBJECT:	Propulsion Valve Make-up Check Valve Failures			
RATING:		CTIVE n is required)	X ALERT (Potential Problem)	
		RMATION n is optional)	PRODUCT IMPROVEMENT (Enhance Product)	
MACHINE MODEL(S):		Super B Spike Drivers Hydra-Hammer A & B		
SERIAL NUMBER(S):		Super B Spike Drivers: All Hydra-Hammer A & B: 1001-1043		
SUMMARY:		Replace the Make-up Check Valves in the Propulsion Valves, p/n 83404824 (Manually Operated Valve) and 83404836 (Electrically Operated Valve) with a Plug, p/n 23164405.		
OPERATIONAL IMPACT:		There are 2 Make-up Check Valves in each Propulsion Valve. These check valves help to prevent cavitation of the travel motor when the machine is coasting. If one of the check valves fails, the machine will not propel in one direction. Replacing the check valves with these plugs will eliminate the check valve. Because there is an external make-up check valve added into the hydraulic system, the internal check valves are not required and may be removed with no damage to the motor.		
ACTION:		The Propulsion Valve must be removed from the machine. The 2 check valves are removed and replaced with the plugs. The Propulsion Valve is then reinstalled on the machine. It should take about 2 hours to make the change. See Page 2 for check valve location.		
WARRANTY:		None		



Check Valve Location



Check Valves Located on Bottom Surface of Valve Manual Valve Shown – Flectric Valve is Similar



Bottom Surface of Valve

