

Nordco Machine Spare Parts



Rail Crane Basic Spare Parts Package

The Nordco Rail Crane Basic Spare Parts Package includes high wear and critical components needed to keep your machine in top working condition, and back in service as quickly as possible.

SPRC01B Basic Spare Parts Package

QTY	PART #	DESCRIPTION
10	4200-5	BEARING
4	A-22183	BUSHING, BRAKES
4	A-22182	BUSHING, BRAKES
4	4442	LOCK KEYS, BRAKES
2	54259814	PIN, BRAKE CANNISTER, $\varnothing 1-1/8"$
2	C-22063	PLATE, SWING LOCK FOR TRAVEL
2	B-10740	PULL PIN, SHIM PLATE
1	5200-3	RETAINER
5	7612	RING,RETAINING
4	4441	SHOES,BRAKE
10	A-10726	SPACER
1	F-323	VALVE,SAFETY
1	1606535	VALVE,UNLOADER PILOT VALVE



Nordco Parts
800-647-1724

Nordco
245 W Forest Hill Ave.
Oak Creek, WI 53154 USA
Phone: 414-766-2180
Fax: 414-766-2379
www.nordco.com